



14385 Veterans Way Moreno Valley, CA 92553  
Phone: (951) 571-0212 Fax: (951) 571-0215

**19-21 DODGE RAM 1500 4WD  
CSS-D16-7  
6.5" FRONT COILOVER SPACER**

**READ THE FOLLOWING NOTES PRIOR TO INSTALLATION**

DO NOT ALTER THE FINISH OF ANY COMPONENTS. CHANGING THE FINISH SUCH AS CHROMING, ZINC-PLATING, OR ANY TYPE OF PAINTING, CAN CAUSE STRUCTURAL FATIGUE OF COMPONENTS.

PRIOR TO INSTALLATION, COMPARE THE PARTS LIST WITH THE COMPONENTS RECEIVED IN THE KIT. IF ANY PIECES ARE MISSING PLEASE CONTACT YOUR LOCAL RETAILER OR CST PERFORMANCE SUSPENSION AT 951-571-0212, AND YOU WILL BE TAKEN CARE OF IN A TIMELY MANNER.

READ ALL INSTRUCTION FROM START TO FINISH BEFORE BEGINNING INSTALLATION. IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED, SEVERE FRAME, TIRE, OR SUSPENSION DAMAGE MAY RESULT TO THE VEHICLE. IF YOU INCUR A PROBLEM DURING THE INSTALLATION OF THIS KIT, FIRST BE SURE YOU HAVE FOLLOWED THE INSTRUCTION FROM START TO FINISH ACCURATELY AND IF SO PLEASE CALL 951-571-0212, WE WILL DO OUR BEST OVER THE PHONE TO ASSIST YOU WITH YOUR PROBLEM, OR DIRECT YOU ACCORDINGLY.

VEHICLES THAT RECEIVE OVER SIZED TIRES SHOULD CHECK BALL JOINTS, TIE ROD ENDS AND PIVOT POINTS, AS WELL AS GENERALLY INSPECT THE ENTIRE SUSPENSION FRONT TO REAR EVERY 2500 – 5000 MILES FOR WEAR AND REPLACE PARTS AS NEEDED.

ALSO, WE WOULD LOVE TO SEE YOUR TRUCK COMPLETED. IF YOU WOULD LIKE TO HAVE YOUR VEHICLE FEATURED ON OUR SOCIAL MEDIA PAGES, PLEASE E-MAIL US AT [sales@cstsuspension.com](mailto:sales@cstsuspension.com) WITH PICTURES OF YOUR VEHICLE, LIST OF MODS, YOUR ACCOUNT NAME AND WE WILL GET THEM POSTED. THANK YOU FOR SUPPORTING CST!!!



@CSTSuspension



@CSTSuspension

**INSTRUCTIONS:**

1. These coilover spacers are designed for the CSS-D3-1 6.5" 2019 Dodge Ram 1500 4wd kit.
2. At this point in the installation, your front should be disassembled.
3. Place the CST spacer on top of the factory coilover using the factory hardware with Loctite.
4. Install the factory coilover with the CST spacer into the truck using the supplied 7/16" nuts and washers into the top mount.
5. Continue with the rest of the installation of the kit.



**For technical assistance call CST at 951-571-0212**

**Or e-mail us @ [sales@cstsuspension.com](mailto:sales@cstsuspension.com)**

**Thank you for buying CST Performance Suspension!**