



14385 Veterans Way Moreno Valley, CA 92553
Phone: (951) 571-0212 Fax: (951) 571-0215

CSS-C2-21

11-19 GM 2500/3500 HD Upper Control Arms with Hi Angle Ball Joint & OEM Rubber Style Bushings

READ THE FOLLOWING NOTES PRIOR TO INSTALLATION

DO NOT ALTER THE FINISH OF ANY COMPONENTS. CHANGING THE FINISH SUCH AS CHROMING, ZINC-PLATING, OR ANY TYPE OF PAINTING, CAN CAUSE STRUCTURAL FATIGUE OF COMPONENTS.

PRIOR TO INSTALLATION, COMPARE THE PARTS LIST WITH THE COMPONENTS RECEIVED IN THE KIT. IF ANY PIECES ARE MISSING, PLEASE CONTACT YOUR LOCAL RETAILER OR CST PERFORMANCE SUSPENSION AT 951-571-0212, AND YOU WILL BE TAKEN CARE OF IN A TIMELY MANNER.

READ ALL INSTRUCTION FROM START TO FINISH BEFORE BEGINNING INSTALLATION. IF THESE INSTRUCTIONS ARE NOT PROPERLY FOLLOWED, SEVERE FRAME, TIRE, OR SUSPENSION DAMAGE MAY RESULT TO THE VEHICLE. IF YOU INCUR A PROBLEM DURING THE INSTALLATION OF THIS KIT, FIRST BE SURE YOU HAVE FOLLOWED THE INSTRUCTION FROM START TO FINISH ACCURATELY AND IF SO PLEASE CALL 951-571-0212, WE WILL DO OUR BEST OVER THE PHONE TO ASSIST YOU WITH YOUR PROBLEM, OR DIRECT YOU ACCORDINGLY.

VEHICLES THAT RECEIVE OVER SIZED TIRES SHOULD CHECK BALL JOINTS, TIE ROD ENDS AND PIVOT POINTS, AS WELL AS GENERALLY INSPECT THE ENTIRE SUSPENSION FRONT TO REAR EVERY 2500 – 5000 MILES FOR WEAR AND REPLACE PARTS AS NEEDED.

INSTRUCTIONS:

1. Jack up the truck and support it under the frame with jack stands, never work under an unsupported vehicle.
2. Remove the wheels.
3. Put a floor jack under the lower arm and compress the suspension a couple of inches.
4. Loosen the nut for the upper ball joint; leave it on by about 1/4”.
5. Use a puller to separate the tapered ball joint pin from the upper taper.
6. Note the position of the alignment cams.
7. Remove the cam bolts and remove the arms.
8. Install the new arms, use the stock alignment cams, and put them approximately in the same location they came off. Before tightening, cycle arm and make sure nothing is interfering (Do not tighten at this time).
9. Slide the ball joint pin into the spindle and secure it using the supplied nut and washer. If necessary, you can apply downward pressure on the arm to wedge the taper into the spindle to keep it from spinning while you tighten the nut.
10. Grease ball joint using grease gun (Approximately 4 pumps).
11. Install ball joint cap with supplied O-Ring.
12. Repeat for the other side of the truck.
13. Reinstall wheels and torque to 100 ft.lbs.
14. Once truck is on the ground, tighten the Cam bolts.
15. Have the truck professionally aligned.

Also, we would love to see your truck completed. If you would like to have your vehicle featured on our social media accounts, please e-mail us at sales@cstsuspension.com with pictures of your vehicle, your account name and we will get you posted. Thank you for supporting CST!!!



@CSTSuspension



@CSTSuspension

For technical assistance call CST at 951-571-0212

Or e-mail us at sales@cstsuspension.com